

Colour Cosmetics



Holographic Eye Shadow

Formula reference: SL.CC.36.184

<i>Ingredient / INCI Name</i>	<i>Function</i>	<i>w/w</i>
Phase A		
Mica	Bulking	20.00
SharoSENSE™ Plus 184 (Maltol, Didecyldimonium Chloride)	Preservative Solution	0.50
Oryza Sativa Strach	Bulking, Binding	19.50
Phase B		
Silica, C.I. 77891, Tin Oxide	Cosmetics Colorant	45.00
Synthetic Sapphire, CI. 77491	Cosmetics Colorant	1.50
Mica, C.I.77891, C.I. 77510	Cosmetics Colorant	3.50
Nylon-12	Bulking	10.00

Color cosmetics in powder form can benefit from a powdered preservative, This eye shadow is preserved with SharoSENSE™ Plus, high efficacy solution, inspired by nature and tested for ocular area.



Processing guidelines:

1. Mix phase A until homogenous.
2. Add phase B mixing until homogenous.